

INSTALLATION INSTRUCTIONS FOR 3 + 1 COLUMNS

1. Measure height of finished post in field.
2. Cut column sides to desired length less 1" for the thickness of cap.
3. Notice that the column is glued together on 3 sides with one side loose. Separate loose side from glued sides.
4. First slide in the 3 pc. column section around existing post (leaving 1" on top for the cap), then apply supplied PVC glue in the 2 lock miter joints from top to bottom on both sides of section while getting no glue on the face of column. Install clamps on column as needed (every 24").
5. Secure column wrap to the existing post on the very top and the very bottom (making certain that base and cap will cover any fasteners).
6. Place supplied, quick-drying glue on the ¾" thick top cap inside mitered edges, place both pieces around the column at top until the glued ends meet. Hold for 10 – 15 seconds for glue to dry. Once glue is dry fasten to bottom of beam or ceiling and center 4 sides on column wrap. Once cap is centered on column wrap fasten to underside of beam making sure that the top base will cover fasteners.
7. Place supplied, quick-drying glue on the top base inside mitered edges and place both pieces around column (around eye level) till the glued ends meet and hold for 10-15 seconds for the glue to dry. Once dry place the same glue on the top 4 edges of the top base, slide the top base up to the underside of top cap and hold for 10 -15 seconds for glue to dry. Do the same for the two pieces of crown material (if purchased with column).
8. Place supplied quick-drying glue on the mitered edges of the bottom base as well as the perimeter of the back of the bottom base and place both pieces around bottom of column till the two glued ends meet. Hold for 10 –15 seconds for glue to dry.

CAREFUL OF GLUE. . . IT SETS UP VERY FAST (SEE BOTTLE FOR DETAILS)

Please call us with any additional installation questions at (860) 758-7900.