

INSTALLATION INSTRUCTIONS FOR CORNER POSTS

This is a two man job

1. Install supplied brackets to hang approximately 1" below top of foundation. (Industry standard)
2. Install brackets into substrate with supplied stainless steel screws.
3. Cut corner to desired length.
4. With 2 men, lift corner post on top of brackets into position.
5. Nail vinyl nailing flange in every other nail slot from top to bottom with 1 ½" roofing nails.
6. If corner post came with cap and base, the corner posts body must be cut ¾" shorter than the desired finish length to allow for top cap thickness. With the corner post on a set of saw horses, the top cap is installed on the corner prior to installation with 2 screws down through the top of the cap into the body of the corner post. With 2 men, lift corner post onto the corner brackets. Nail vinyl nailing flange in every other nail slot from top to bottom. Apply supplied glue to back of base every 2-3" on perimeter and hold against bottom of corner for 10-15 seconds to allow for glue to dry.

BE CAREFUL OF GLUE. . . IT SETS UP VERY FAST (SEE BOTTLE FOR DETAILS)

Please call us with any additional installation questions at (860) 758-7900.