



INSTALLATION INSTRUCTIONS FOR WINDOW SURROUNDS

1. Prior to window surround install, ensure that window has been installed per manufacturer's specs.
2. Place surround around window frame with even reveal on all 4 sides, nail vinyl flange with 1 ½" roofing nails in every other hole on all four sides.
3. Using weather resistant tape (not supplied), apply tape half on flange and half on building wrap on the top and sides of the surround (not on the bottom) to ensure a proper installation.

Please call us with any additional installation questions at (860) 758-7900.