



## **INSTALLATION INSTRUCTIONS FOR WINDOW & DOOR MANTELS**

1. Prior to mantel install, ensure that window or door is installed per manufacturer's specs.
2. Rest mantel on window or door frame top and center. Remove the mantel removable strip and set aside.
3. Nail the nail flange in every other hole with 1 1/2" roofing nails on all sides.
4. Install the supplied screws in pre-drilled holes in removable strip groove. Choose which side of the removable strip you want showing (plain or dentil). Apply glue to the opposite side of the strip and press the removable strip into the groove and hold for 10 – 15 seconds.
5. Using weather resistant tape (not supplied), apply half on flange and half on building wrap to ensure a proper installation.

Please call us with any additional installation questions at (860) 758-7900.