

QuickTrim Transition Board

INSTALLATION INSTRUCTIONS

1. Unwrap Transition board from packaging – measure and cut to desired length
2. Position Transition board where desired
3. Nail both sides of nailing flange, every other hole with 1-1/2” roofing nails
4. After Transition board is installed, apply weatherization tape ($\frac{1}{2}$ on flange and $\frac{1}{2}$ on building wrap) for a water tight application

Helpful Tip:

- If warm outside - butt Water Table boards up-tight
- If freezing temperatures outside - leave $\frac{1}{4}$ ” between Water Table boards to allow for expansion and contraction