

QuickTrim Trim Board

INSTALLATION INSTRUCTIONS

APPLIES TO 4" AND 6" QUICKTRIM TRIM BOARDS

1. Unwrap QuickTrim Trim Board from packaging – measure and cut to desired length
2. Remove 3/8" Starter Strip from side of QuickTrim board
3. Install 3/8" Starter Strip in desired location with 1-1/2" roofing nails (gables, rakes, rooflines etc..) nail in center of slots of Starter Strip
4. Slide bottom of QuickTrim Trim Board onto 3/8" Starter Strip and nail Nailing Flange on opposite side in every other hole with 1-1/2" roofing nails
5. After QuickTrim Trim Board is installed, apply weatherization tape (½ on the flange and ½ on the building wrap) for a water tight application

Helpful Tip:

- If warm outside - butt QuickTrim Trim Boards up-tight
- If freezing temperatures outside - leave ¼" between QuickTrim Trim Boards to allow for expansion and contraction